

**Battery tray.**

Areas around battery tray, adjacent to valance lower.



**Bolt heads.**

Lightly coat all wing, bonnet locking platform and front panel bolt heads.



**'A' Post upper. ( Later models only ).**

Remove clear plastic blanking plug and retain for reuse. Access through hole adjacent to windscreen corner. Spray 360 degrees. Wipe off excess product from painted surfaces. Coat plug with product prior to re-fitting.



**Front wing.**

Return flange at trailing edge of wing.  
( Full height of wing ).

