

Front door.

Remove black blanking grommet from lower rear edge and retain for reuse. Treat area adjacent to hole, including between double skinned area. Spray 360 degrees. Wipe off excess product from painted surfaces.



Front door.

Lightly treat internal lower seam.



Front door hinges.

Lightly coat hinges.

