

Front door.

Lightly treat internal lower seam.



Rear door hinges.

Lightly coat hinges.



'B'/C' post.

Access through hole adjacent to upper hinge, rear door.

Remove blanking plug. Spray 360 degrees.

Wipe off excess product from painted surfaces.

prior to fitting. Coat new plug with product



Rear door.

Remove black blanking grommet from lower rear edge

and retain for reuse. Treat area adjacent to hole,

including between double skinned area. Spray 360 degrees.

Wipe off excess product from painted surfaces.

