

Boot area.

Access through small hole in centre of boot floor above floor crossmember. Feed tube sideways into cavity to full extent. Withdraw tube whilst spraying. Feed tube in opposite direction and re-treat. Wipe off excess product from painted surfaces.



Boot area.

Access through cut-out at centre of boot hinge panel box section. Feed tube sideways into cavity to full extent. Withdraw tube whilst spraying. Feed tube in opposite direction and re-treat. Wipe off excess product from painted surfaces.



Boot area.

Access through end of boot hinge panel box section. Feed tube sideways into cavity to full extent. Withdraw tube whilst spraying. Feed tube in from opposite end and re-treat. Wipe off excess product from painted surfaces.

