

Upper rear panel.

Access through holes in each end of box section, underneath rear parcel shelf. Feed tube sideways from left hand end, into cavity to full extent. Withdraw tube whilst spraying. Feed in tube from right hand end and re-treat. Take care not to dislodge rear washer feed pipe from back of nozzle. (Where fitted) Wipe off excess product from painted surfaces.



Using the rigid lance, treat the following areas.

Front wing area.

Access through rear edge aperture, between wing and lower a post. Feed in lance to full extent to top corner of wing above headlamp. Withdraw lance whilst spraying. Feed in lance to full extent to lower front corner of wing below headlamp. Withdraw lance whilst spraying.

