

**Front door.**

Access through hole in lower rear edge. (Grommet previously removed) Feed in lance towards front of door to full extent. Take care not to disturb wiring or door mechanisms. Withdraw lance whilst spraying. Coat blanking grommet with product prior to refitting. Wipe off excess product from painted surfaces.

**Rear door.**

Access through hole in lower rear edge. (Grommet previously removed) Feed in lance towards front of door to full extent. Take care not to disturb wiring or door mechanisms. Withdraw lance whilst spraying. Coat blanking grommet with product prior to refitting. Wipe off excess product from painted surfaces.

**4. c. Underbody areas.**

Using the flexible tube, treat the following areas.

**Front suspension crossmember.**

Access through two holes in underside of crossmember. Feed tube into cavity through left hand hole, towards left hand side of vehicle to full extent. Withdraw tube whilst spraying. Feed tube through left hand hole, towards centre of vehicle. Withdraw tube whilst spraying. Repeat process through right hand hole.

