

Rear axle snubber.

Treat area between rear axle snubber and vehicle floor,
(photo 02069)



02069

Rear wing inner and outer.

Access through rearmost outer corner of body, inside of rear bumper end cap.
Feed tube forward into cavity to full extent. Withdraw whilst spraying.



5. Completion of process.

After the retreatment process has been carried out, check the following items:

Check that all drain holes are clear of any blockage. E.g. lower edges of doors and sill sections.

Ensure that all blanking plugs and grommets are correctly re-fitted.

Wipe off any remaining product from painted surfaces, bumpers etc. Pay particular attention to the D post area.

Check functionality of all moving windows and rear door courtesy light switches to ensure that the wiring has not been disturbed.

Re-fit boot carpet (where fitted) and integral step in boot.

END